


INSTALLATION MANUAL








38120P, 38140P, 38150P, 38220P, 38240P, 38250P



100 - 240V | T8 LED | IP65 | PC+PC



100 - 240V | 2xT8 LED | IP65 | PC+PC



Wiring diagram.

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.